

HY- 6900
HY-7700
SERVICE MANUAL

NOTE

THIS SERVICE MANUAL IS
GUARANTEED EFFECTIVE
FOR SERIAL NO.
ONLY.

CAUTION

- DO NOT** OPERATE IN REVERSE MODE TO MOVE VESSEL FORWARD
- DO NOT** OPERATE CONTINUOUSLY IN REVERSE MODE FOR MORE THAN 30 MINUTES AT 75% OF AVAILABLE HORSEPOWER.
- DO NOT** OPERATE UNIT OVER 180° F (82°C)
- DO NOT** OPERATE UNIT WITH HIGH OR LOW OIL PRESSURE
- DO NOT** 'WINDMILL' UNIT IN EVENT OF ENGINE FAILURE (PROP SHAFT SHOULD BE LOCKED TO PREVENT 'WINDMILLING').
- DO NOT** ATTEMPT FINAL ALIGNMENT OF OUTPUT FLANGE AND PROP SHAFT COUPLING WHEN VESSEL IS IN DRY-DOCK.
- DO NOT** SHIFT TRANSMISSION UNLESS ENGINE IS AT IDLE SPEED.
- DO NOT** USE TRANSMISSION TO SUPPORT REAR OF ENGINE.

Table of contents

	page
Section 1. Introduction	
1.1 description	1
1.2 Optional Equipment	1
Section 2. Principles of Operation	
2.1 Output rotation	2
2.2 Reduction Ratio	2
2.3 Power Flow	3
2.4 Clutch	3
2.5 Hydraulic System	4
Section 3. Installation and Operation	
3.1 Uncrating and Handling	5
3.2 Installation Preparation	5
3.3 Installation of Transmission	7
3.4 Alignment of Output Coupling	8
3.5 Water piping	9
3.6 Start-up Procedure	11
3.7 Operating Practices	11
Section 4. Preventive Maintenance	
4.1 Lubricants	12
4.2 Routine Maintenance	12
4.3 Maintenance Schedule and Check Sheet	13
Section 5. Trouble Shooting	
5.1 Trouble/Remedy Chart	14
Section 6. Repair of External Sub-Assemblies	
6.1 Oil pump	17
6.2 Selector Valve	20
Section 7. Repair of Internal Sub-Assemblies	
7.1 Removal of Reverse Gear	22
7.2 Table: Replacement Wear Limits	23
7.3 Clutch	24
7.4 Pinion Shaft: Removal and Reassembly	29
7.5 Output Gear and Related Parts	31
7.6 Housing Parts	32
7.7 Reassembly and installation of Output gear and related parts	33
7.8 Installation of Output Coupling	35
7.9 Installation of Pinion shaft and Related parts	35
7.10 Post-Assembly Inspection	36
7.11 Additional Assembly	37
7.12 Adapter Parts	38
Section 8. Part Information	
8.1 Part Ordering Procedure	40
8.2 Unit Record	40
8.3 Selector Valve	41
8.4 Oil pump	42
8.5 Clutch	44


Table of Contents (Continued)


8.6	Transmission Housing and Related Parts	46
8.7	Adapter Group	49
8.8	Pinion Shaft and Related Parts	50
8.9	Idler Gear and Related Parts	50
8.10	Output Gear, Cover and Related Parts	52
8.11	Reduction Gear Selection Chart	54
8.12	Oil Filter	55
8.13	Propeller Coupling Kits	56
8.14	Oil Coolers	57
8.15	Hose and Fitting Kit	58
8.16	Housing and Related Parts (Hy-6900)	59
8.17	Pinion Shaft and Related parts (Hy-6900)	62
8.18	Output Gear and Related Parts (Hy-6900)	64
8.19	Reduction Gear selection Chart (Hy-6900)	66

Section 9. Reference

Installation drawings

Cross- section Assembly drawings





Cross Section Showing Components and Design Features

SECTION 1. INTRODUCTION

The purpose of this manual is to provide assistance to operation and maintenance personnel to reduce downtime and obtain consistent performance.

This service manual contains thorough installation and operation procedures, steps for proper maintenance and repair, a trouble shooting guide for assessing difficulties promptly, an illustrated parts information section, and engineering drawings for fabricating special tools. It should be made readily available to all those responsible for the operation or servicing of the reverse gear.

Performance characteristics and other details may be obtained from the engineering department of Capitol Gears, Inc., St. Paul, Minnesota, U.S.A.

1.1 DESCRIPTION

The Capitol marine transmission is operated hydraulically. The clutch is activated by high-pressure oil and the gears, bearings and clutch discs are lubricated and cooled by low-pressure oil.

The marine gear consists of six major groups of parts; adapter group, clutch pack, oil pump, selector valve, pinion shaft and reduction gear. The adapter parts vary according to engine application and include a flywheel adapter, drive flange, and oil dam adapter to prevent engine contamination and driving drum. The clutch pack consists of reciprocating cylinders, clutch discs and a planetary bevel gear reversing system. The oil and pump supplies oil pressure for clutch engagement and lubrication of bearings,

gears and clutch. The selector valve is used to obtain forward, neutral or reverse. The one-piece pinion and shaft drives the output gear directly or through and intermediary gear called and idler.

1.2 OPTIONAL EQUIPMENT

OIL COOLER

Various capacity oil coolers for salt or fresh water are available depending on engine size and are purchased optionally. However, oil cooler must be used with a capitol marine transmission.

HOSE AND FITTING PACKAGE

Kits that include the necessary hose and fittings are available for use with capitol oil coolers.

PROP COUPLING KIT

A prop shaft coupling kit is available to meet most requirements

POWER TAKE-OFF

A one-way clutch may be furnished for power take-off reduction gears (HP PTO series.)


INDEPENDENT MOUNT

For installations where the transmission is not to be bolted directly to the engine, a keyed input shaft is available.

SECTION 2. PRINCIPLES OF OPERATION

2.1 OUTPUT ROTATION

The capitol marine gear in forward mode provides output rotation in the opposite direction as engine rotation. The marine gear unit is normally supplied for a right hand engine (when viewed from the front). This produces a right hand rotation output of the prop shaft in forward (When viewed from the rear of the transmission.) For twin-screw installations, where two right hand engines are used, the port unit is furnished with an idler gear. The idler gear produces, in forward, an output rotation the same as engine rotation. Thus the two propellers can be turning opposite each other in outboard direction (see diagram below). Note: Engine rotation transmissions are installed on right hand engines only.



2.2 REDUCTION RATIO

The reduction ratio is the number of teeth in the reduction gear compared to the number of teeth in the pinion, for example, 144 teeth compared to 36, or 4 to 1. Output speed then is a product of engine r.p.m. and the reduction ratio, for example 200 r.p.m. X ¼ = 500 r.p.m. output speed.

2.3 POWER FLOW

The flywheel adapter, being directly fastened to the engine flywheel continually rotates the drive flange assembly, clutch-driving drum and forward clutch discs at engine speed.

NEUTRAL

In neutral no direct torque is applied to clutch and pinion. Consequently reduction gear and output flange do not rotate.

FORWARD (See figure 2.)

When forward is selected the entire clutch becomes locked with the driving drum and rotates at engine speed. The clutch drives the pinion in engine direction and the pinion drives the reduction gear and output flange in anti-engine direction at a speed determined by the reduction ratio.




Figure 2. Power Flow (in forward mode)


2.3 POWER FLOW (CONT'D.)

REVERSE

When reverse is chosen the clutch is held stationary to the housing. Engine power is transferred through the clutch bevel gears and the pinion is driven in anti-engine rotation at engine speed. This causes reduction gear and output flange to rotate in engine direction (reverse).

2.4 CLUTCH


The clutch assembly is a multiple disc type clutch activated by a hydraulic mechanism. This mechanism is formed by a carrier for the bevel gears and by two cylinders bolted together which act as the clutch pistons. The movement of the cylinders is regulated by the selector valve which directs pressurized oil to the proper cylinder depending on the mode selected. The bevel gears inside the carrier transmit power flow to the pinion.



FORWARD MODE


At all times, stub shaft (1), clutch driving drum (2) and driving gear (8) are turning in engine rotation direction at engine speed.

Forward is achieved when selector valve is shifted to allow oil to pressurize forward half of cylinder (3). Cylinder then slides on bevel gear carrier (4) clamping clutch discs (5) together. Half of discs are splined to forward driving drum and half are splined to end flange (6). Because end flange is bolted to gear carrier and discs are now locked together, gear carrier with bevel gears (7) now rotates at engine speed along with driving gear. Rotating bevel gears cause driven gear (9) to turn with them and this causes rotation of output shaft in forward rotation.



NEUTRAL MODE

Both halves of clutch cylinder (1) are filled with pressurized oil. Cylinder cannot press against either forward (2) or reverse clutch discs (3). Discs splined to driving drum (4) and reverse drum (5) remain separate from discs splined to end flanges (6) & (7). Consequently no direct torque is applied to gear carrier (8) or driven gear and output shaft (9) & (10). Bevel gears may revolve on their own shafts and gear carrier orbits at half engine speed.



REVERSE MODE


Reverse is achieved when cylinder (1) is pressurized and slides against reverse clutch discs (2) clamping them together. Half of the discs are splined to the stationary reverse drum (3) and half are splined to end flange (4) bolted to gear carrier (5). Rotating gear carrier then stops. The bevel gears (6) now rotate on their shafts causing driven gear (7) to turn in anti-engine direction producing reverse output.

2.5 HYDRAULIC SYSTEM

is drawn from the sump through a suction hose and then sent under pressure to a filter and an oil cooler and then to the selector valve. The selector valve is used to obtain forward, neutral or reverse by routing the high-pressure oil through internal passages to the clutch. Low-pressure oil is channeled to cool bearings, gears and clutch discs. An oil dam keeps the transmission oil within the transmission housing.

In neutral the ports to both the forward and reverse sides of the clutch cylinder are opened and the balanced pressure that results keeps the clutch cylinder centered between the forward and reverse clutch discs. Oil is distributed through the lubrication system.

When the selector valve is shifted to either forward or reverse mode high pressure oil is allowed to flow only to one half of the clutch cylinder to engage the selected pack. Oil in the other half of the cylinder is exhausted to sump. In forward or reverse, oil is also distributed through the lubrication system.



SECTION 3. INSTALLATION AND OPERATION

NOTE: IMPROPER INSTALLATION AND ALIGNMENT IS THE GREATEST CAUSE OF GEAR FAILURE. PLEASE FOLLOW INSTRUCTIONS CAREFULLY.

3.1 UNCRATING AND HANDLING

Tapped holes have been provided for insertion of eyebolts to aid in handling the unit. Average weight of HY-7700 is 1230 lbs.

Check parts for shortage and any damage that may have occurred (the parts information section may be used as reference). Report immediately any shortage or damage to your local distributor, transfer agent or Capitol Gears.

3.2 INSTALLATION PREPARATION

SPECIAL TOOLS REQUIRED

1. Chain hoist or equivalent
2. Straight edge
3. Feeler Gauge
4. Thousandths dial indicator

To insure proper alignment of driving members it is recommended that engine flywheel housing, flywheel, oil dam adapter, and stub shaft be dial indicated to insure trueness.

1. (Fig.3A) Dial indicates the bolt face of the engine flywheel-housing flange. Rotate engine flywheel. Record reading. Face deviation must not exceed a **total indicator reading** of .007 inch.
2. (Fig.3B) Mount indicator with stern riding on flywheel housing bore as shown. Rotate flywheel and record reading. The bore eccentricity must not exceed a **total indicator reading** of .007 inch.

3. (Fig.3c) Mount indicator to flywheel housing so that stern is on inner face of flywheel; record deviation of face run out. It must not exceed a **total indicator reading** of .007 inch.

4. (Fig.3D) set stern to ride on the pilot bore of the engine flywheel as shown. Record reading. Pilot bore eccentricity must not exceed a **total indicator reading** of .007 inch.

The sum of all readings in steps 1 through 4 must not exceed .007”.

NOTE:

Keep all mating surfaces clean. Use cleaning solvent or diesel fuel.

5. Remove the clutch assembly from the clutch-driving drum and drive flange assembly (drive flange and flywheel adapter).
6. Remove clutch-driving drum from flywheel adapter (Leave drive flange attached to flywheel adapter).
7. Thoroughly clean flywheel adapter to engine flywheel-mating surfaces and secure flywheel adapter (and drive flange) to engine flywheel with capscrews and lock washers.
8. Locate oil dam adapter on engine flywheel housing with drain slots down. Secure oil dam tentatively with capscrews and lockwashers.




Figure 3. Dial Indicating Flywheel Housing and Engine Flywheel




Figure 4. Dial Indicating Oil Dam Adapter Pilot O.D.

9. Dial oil dam pilot O.D. as shown in figure 4. record reading. Total indicator reading must not exceed .007 inch.




Figure 5. Dial Indicating Oil Dam Adapter Bolt Face

10. Dial indicates oil dam bolt face as shown in figure 5. Record reading. Total indicator reading must not exceed .007 inch




Figure 6. Dial Indicating Stub Shaft

11. Dial indicate stub shaft on chamfer as shown in figure 6. Record reading. Total indicator reading must not exceed .007 inch.

The sum of readings in steps 4, 5 and 6 must not exceed .007 inch.

12. Using an adequate hoist, install clutch on splines of drive flange shaft being careful that clutch disc teeth enter driving drum properly. Be sure that the forward end flange marked "toward engine" is placed toward the engine flywheel. The forward pack contains the greater number of clutch discs and must go toward the engine flywheel. Otherwise reverse damage to clutch may result.




Figure 7. Sequence of Assembly: Adapter Parts, Clutch and Housing

3.3 INSTALLATION OF TRANSMISSION

1. Apply a small amount of grease to oil dam adapter and locate gasket.
2. Remove side inspection covers to facilitate installation.
3. Remove oil pump and oil pump drive shaft.
4. Using an adequate hoist and hoist guide (special tool no. 1-90021-0000) lift transmission into position behind engine. Ease unit forward over clutch assembly gently twisting transmission housing so that discs enter reverse drum properly without damaging teeth. A screwdriver may be used through the side inspection hole to align disc teeth with the reverse drum.
5. Secure transmission housing to oil dam adapter with capscrews and lockwashers.
6. Check clutch end float: insert screwdriver through side inspection hole and pry clutch fore and aft. See fig. 20, page 22. End float should be 1/16" to 3/32".
7. Turn output coupling over for several revolutions making sure unit is free to turn.
9. Replace oil pump drive shaft, gasket and oil pump. Secure pump with cap screws and lock washers.




Figure 8. Locating Transmission Housing on Oil Dam Adapter




Figure 9. Alignment of Output Flange and Propeller Shaft Coupling

3.4 ALIGNMENT OF OUTPUT COUPLING

In marine application, final alignment of output flange and propeller shaft coupling must be accomplished when the vessel is afloat and not in dry-dock, because most hulls will flex. This is positively necessary to meet warranty requirements.

Mounting feet on housing permit unit to be bolted to bed rails, power plant frame, keelsons, etc.

The distance of the first shaft bearing from the mating surface of the reverse gear output coupling is extremely important. To avoid undue force on the reverse gear bearings, the propeller shaft bearing should be located at least twelve and preferably twenty shaft diameters from the reverse gear output coupling.

NOTE:

The same alignment procedures should be followed even if a flexible coupling is used. The most accurate method is to use a non-flexible spacer of the same size first. Flexible couplings are used only to dampen noise and vibration and to correct minor misalignment.

Now align shaft coupling to reverse gear coupling. Lay a straight edge across the edges at top and sides to line up couplings. Do not burr or mar mating surfaces. Insert feeler gauge between couplings and run it all around the flange. Clearance should not be more than .006" at any point. Shim engine and reverse gear as necessary. Mounting feet have threaded holes for jacking screws.

Loosen gear housing to engine housing bolts and check with feeler gauge. Maximum variation for SAE "0 housing is .008"; for SAE #1 housing is .006".

Tighten four gear housing capscrews at 90° intervals. Secure engine and gear mounting feet. Loosen four gear-housing bolts. Recheck housing and coupling parallelism. If within limits tighten housing and coupling bolts.

Be sure transmission is connected to oil cooler.

NOTE:

Under no condition is the engine to be supported by gear housing.

3.5 WATER PIPING

To assure proper cooling of the Capitol's reverse gear units, connect the cooling system as indicated on one of the three diagrams shown. It is extremely important that the marine gear oil be cooled properly; the oil cooler must receive an ample supply of cold water.




Figure 10. Separate pump system




Figure 11. Heat exchange system





Figure 12. Keel cooler system.



CAUTION: ALWAYS USE BACKUP WRENCH ON COOLER FITTINGS

3.6 START-UP PROCEDURE

1. Remove oil breather or top inspection cover and add recommended oil until level is up to full mark on dipstick (see lube chart, p.12). Replace but do not secure.
2. Install pressure gauge of 300-pound capacity directly on top of gear or on bulkhead. Connect gauge to control valve with hydraulic hose. (Note: Electric type oil pressure gauges are not recommended.)

Reverse gear is now ready to start up:

3. Engage starter for approximately 30 seconds, but DO NOT START ENGINE. This activates pressure pump which pre-lubricates reverse gear, preventing premature wear before load is applied.
4. Start engine and check all connections for leaks.
5. Oil pressure is adjusted at factory for testing purposes only and it may be necessary to readjust pressure to the correct level (200-210 PSI). This should be set for normal operating speed and temperature (See fig. 12 below).

NOTE:

Normally unit pressure at idle start-up will be 180 PSI, but final adjustment must be made as noted above.

6. After unit has been operated a few minutes, stop engine, check oil level and add sufficient oil to bring level to full mark on dipstick. (See lube chart for capacities). Secure oil breather or inspection cover

7. Shift several times to insure that all cylinders, hoses and cooler are full of oil.
8. Install selector valve cables and shift to insure valve lever goes into full detent in all 3 positions; forward, neutral and reverse.

NOTE:

We strongly recommend installing an interlock control system, which prevents shifting at other than engine idle speed and greatly prolongs life of the gear.

9. Reverse gear is now ready for sea trials and final adjustments.

3.7 OPERATING PRACTICES

CAUTION

1. A Capitol reverse gear should normally not be shifted unless engine is at idle speed.
2. Reverse gear cannot be operated continuously in reverse mode for more than 30 minutes at 75% of available horsepower.
3. In marine application 'windmilling' (freewheeling) is strictly prohibited as extensive internal damage may result. IN the case of a twin screw application where only one engine may be used a great deal, shaft brakes should be installed. (As an alternative an auxiliary lube system may be installed).
4. Do not operate unit with high or low oil pressure or if oil temperature exceeds 180°F.




Fig. 13. Adjustment of Oil Pressure. CAUTION: Relief Screw is Under Tension.




Fig. 14. Clutch Cylinder Timing Adjustment; used to regulate shifting time.

SECTION 4. PREVENTATIVE MAINTENANCE

To insure a long service life of the Capitol Marine gear and to prevent costly and unexpected failures it is very important that a regular maintenance schedule be established and followed.

4.1 LUBRICANTS

Use oil-meeting requirements of MIL-L-2104B or API SERVICE CLASS. SE/CC. Series 3 oils are not recommended because they may shorten clutch life.

For all normal ambient operating conditions. 30°F (-1°C) to 85°F (29°C), We recommend a good grade, anti-foaming, heavy duty, SAE 30 motor oil.

Where high ambient temperatures are encountered, over 85°F (29°C), it may be necessary to use SAE 40 motor oil.

Where extremely cold ambient temperatures are encountered, under 30°F (-1°C), it may be necessary to use SAE 20 motor oil.

CAUTION:

When using SAE 20 motor oil be very attentive to oil pressures. If proper pressure cannot be maintained (9200-210 P.S.I) it may be necessary to use SAE 30 and warm engine and gearbox thoroughly before engaging clutch. This condition would only be encountered at extremely low temperatures.

Oil Capacity (approximate, depending on cooler, hoses etc.)

7.5 Gallons (28 liters)

Bring oil up to full mark on dipstick. Operate unit in forward and reverse for several minutes. This will fill cooler, clutch cylinders, pump hoses, etc. Stop engine and add required oil to return level to "full" mark on dipstick.

Oil pressure

Operating oil pressure must be at least 200-210 PSI at normal operating speed and maximum operating temperature.

Pressure Adjustment

See fig. 13, p.11

Oil Temperature

Operating oil temperature range is 100°-150°F (38°-66°C) at control valve. Unit will tolerate higher temperatures but clutch life may be shortened considerably.

4.2 ROUTINE MAINTENANCE

Oil Cooler Assembly

Check Zinc pencils in oil cooler and change if badly eroded. Check zinc pencils at approximately every 400 hours of operation.

Check water tubes for obstructions at approximately **every 2000 hours** of operation and flush if necessary.

Oil Filter

The oil filter element should be replaced **every 400 hours** of operation or at the same time oil is changed.

Oil Breather

Remove oil breather **every 400 hours** of operation or the same time oil is changed. Clean diesel fuel can be used for flushing.

Pressure Gauge

Periodically check pressure gauge by substituting a calibrated pressure gauge of known accuracy.

Visual Inspection

At frequent intervals check all oil lines, water hoses, and connections for leaks. Tighten all external bolts and connections and visually inspect external components for wear or damage.

Wear Analysis

At periodic intervals record pressure readings at idle speed; a gradual decline is normal. Readjust pressure relief valve to maintain proper operating pressures. See fig.13, p. 11.

Inspection/ Overhaul interval

A complete inspection of the Capitol marine gear should be made at least as often as the engine is overhauled. Parts such as commutator bushings, oil seals, o-rings, clutch discs, bearings etc. showing any fatigue or wear should be replaced. It may be desirable to completely rebuild the marine gear at this time (see section 7.)

SECTION 5. TROUBLE SHOOTING

5.1 TROUBLE/REMEDY CHART

SYMPTOM	PROBABLY CAUSE	REMEDY
A. Low oil pressure (at full operating speed and temperature)	<ol style="list-style-type: none"> 1. Faulty pressure gauge 2. Low oil level 3. Clogged filter element 4. Clogged suction tube 5. Clogged parts in selector valve, base plate or housing 6. Dirt or sludge in transmission 7. Worn pump assembly 8. Incorrectly adjusted pressure relief valve 9. Oil too hot 10. Worn commutator bushing 11. Incorrect lubricant 12. Scratched clutch cylinders or hard O-ring in clutch cylinders 	<ol style="list-style-type: none"> 1. Check gauge against one of known accuracy 2. Inspect gaskets, seals, hoses and fittings for leakage. Pressure test oil cooler-tubes may leak 3. Replace filter element 4. Remove tube and clean with solvent. Blow dry 5. Flush clean with solvent and blow dry 6. Remove drain plugs, flush gear with commercial solvent or diesel fuel. Start engine; at idle shift gear several times, full forward to full reverse for 3-5 minutes maximum. Shut down engine and drain 7. Refer to oil pump section (Page 17) or fig. 13, p.11. 8. See fig.13 page 11 9. Check heat exchanger system for clogged oil cooler or hoses. 10. See wear limits chart (p.23) 11. See lube chart (p.12) 12. Replace as necessary (p.25)
B. High Oil pressure (At full operating speed and temperature)	<ol style="list-style-type: none"> 1. Incorrect adjusted pressure relief valve 2. Inoperable relief plunger in base plate 3. Incorrect oil 4. Cold oil 5. Cold oil at start-up 	<ol style="list-style-type: none"> 1. Refer to fig.13 p.11 2. Refer to p.17 3. See lube chart (p.12) 4. Check heat exchanger system 5. Transmission should be pre-heated see p.11
C. No Oil Pressure	<ol style="list-style-type: none"> 1. Faulty pressure gauge 2. Broken hose 3. No oil in transmission 	<ol style="list-style-type: none"> 1. check pressure with gauge of known accuracy 2. Replace hose. Inspect all hoses 3. Fill with proper oil. See p.12

D. Overheating	<ol style="list-style-type: none"> 1. Insufficient Oil cooler Capacity 2. Insufficient flow of cooling water 3. Clutch slipping 4. Water temperature too high at cooler 	<ol style="list-style-type: none"> 1. Install adequate oil cooler 2. Increase water line sizes 3. Refer to symptom A 4. Decrease water temperature to cooler or relocate heat exchanger in cooling system.
E. Excessive noise in transmission	<ol style="list-style-type: none"> 1. Bearings worn or broken 2. Gears worn or broken 3. Noise in forward only 4. Noise in reverse only 5. Improper alignment 	<ol style="list-style-type: none"> 1. Inspect bearings for scored races, broken roller, flat -spots, etc. 2. Inspect gears and replace if necessary 3. Reverse position may be mistakenly used for forward. Selector valve lever must point forward when boat is in forward motion. 4. This is normal because more gears are in operation in reverse mode. 5. Refer to section 3, pg.8
F. Noisy Pump	<ol style="list-style-type: none"> 1. Dirt or sludge in oil 2. Clogged hoses 3. Pump cavitation 4. Defective oil pump assembly 	<ol style="list-style-type: none"> 1. Remove oil pump and hoses. Clean thoroughly and reinstall 2. Clean and replace as required 3. Oil level may be too low 4. Refer to oil pump section p.17
G. Clutch does not release	<ol style="list-style-type: none"> 1. Transmission is misaligned 2. Improper oil sump 3. Clutch discs warped 4. Forward and reverse clutch cylinders dirty or distorted 5. Rear commutator bushing is worn 6. Incorrect linkage adjustment to selector valve assembly 7. Clutch discs fused due to slippage and overheating 	<ol style="list-style-type: none"> 1. Refer to installation section 2. Refer to lube chart 3. Replace as necessary 4. Clean or replace as necessary 5. Replace as necessary. See replacement wear limits chart 6. Adjust linkage 7. Replace as necessary
H. Clutch slipping	<ol style="list-style-type: none"> 1. Low oil pressure 2. Transmission is misaligned 3. Oil temperature is too high 4. Worn clutch discs 5. Incorrect linkage adjustment to selector valve assembly 6. Improper oil 	<ol style="list-style-type: none"> 1. See symptom A 2. Refer to installation section 3. Temperature should be 140° to 160°F (60° to 71°C) at selector valve. Check heat exchanger system 4. Replace as necessary, see replacement wear limits chart 5. Adjust linkage 6. See lube chart

I. Clutch burned out	<ol style="list-style-type: none"> 1. Low oil pressure 2. Clutch is shifted at other than engine speed 3. Transmission misaligned 4. Excessive heat 	<ol style="list-style-type: none"> 1. See symptom A 2. Install interlock shift controls 3. Check installation and alignment as described in installation section 4. Check cooling system
J. No Neutral	<ol style="list-style-type: none"> 1. Transmission is misaligned 2. Warped clutch discs 3. Scored clutch cylinders 4. Damaged clutch quad rings 5. Worn or damaged commutator bushings (forward or rear) 6. Worn selector valve 	<ol style="list-style-type: none"> 1. Refer to installation section 2. Replace as necessary 3. Replace as necessary 4. Replace all 4 5. Replace as necessary. See replacement wear limits chart 6. Replace if necessary. Note: selector valve is the least likely source of trouble
k. Clutch engages too low	<ol style="list-style-type: none"> 1. Cylinder timing screw out of adjustment 	<ol style="list-style-type: none"> 1. Remove dome nut and adjust screw (counter-clockwise) to speed up reaction.
L. Clutch engages too fast	<ol style="list-style-type: none"> 1. Cylinder timing screw out of adjustment 	<ol style="list-style-type: none"> 1. Remove dome nut and adjust screw in (clockwise) to delay reaction.